

Perfume Pens

Perfume Pens are wonderful for the ladies! Elegant, fashionable, easy to use, and extremely practical. To care for your new perfume pen, treat it as you would any other piece of fine furniture. Try to avoid exposing your new perfume pen to extremes in temperature and moisture. Most wood products benefit greatly from a light coat furniture wax periodically. Before refilling your pen, clean the applicator tip by soaking it in a household type alcohol for a few minutes but do not use any cleaning solutions on the wood exterior.

Your perfume pen is very easy to fill. Unscrew the cap, do not remove the tip from the pen, simply dip the tip of the pen into your favorite perfume bottle or into a small container where you have poured a small amount of perfume. The pen has an absorbent wick inside which will soak up your perfume. Leave the applicator tip in the perfume for approx. 10-15 minutes, remove, and replace the cap on your pen. The white applicator tip will swell and stay in place when filled with liquid.

To apply your perfume, remove the cap, dab a little on your skin, and replace the cap. Remember to put the cap back on tightly as this prevents spillage and evaporation of your perfume. When the tip is dry, simply refill your pen. If an applicator tip for any reason becomes unusable, replacement applicator tips are available for a reasonable cost.

Hope you enjoy your new perfume pen! Thanks for your purchase!

Our regards,

DK's Wooden Expressions

www.dkwoodenexpressions.com